

# PWI Series Indicators

User Manual





**ESiTi**

PWI Series  
Indicators  
[User Manual](#)



## **IMPORTANT NOTICE!**

**In case the indicator you are using is a part of a scale system that is used for trade, it should be protected with an official seal and be controlled every two years.**

# Contents

<b>Intruduction</b>	<b>1</b>
<b>Specifications</b>	<b>3</b>
Technical Specifications	3
Operation Specifications	4
Display Specifications	5
Control Specifications (Option)	5
<b>Physical Dimensions</b>	<b>7</b>
<b>Apperance</b>	<b>11</b>
<b>Displays</b>	<b>11</b>
<b>Keys</b>	<b>14</b>
<b>Assembling the PWI Indicator</b>	<b>15</b>
<b>Safety Precautions</b>	<b>17</b>
<b>Basic Flow of the PWI Indicator</b>	<b>18</b>
<b>Parameters</b>	<b>20</b>
Loadcell Test (LCTEST)	20
<b>Parameter Entry (SETUP)</b>	<b>21</b>
Digital Filter	21
Decimal Point	23
Scale Type	24
CAP-E2 (Max. Allowable Weight)	25

e <sub>2</sub> (Weighing Steps Display Resolution)	26
CAP-1 (First Interval)	27
e <sub>1</sub> (Weighing Steps Display Resolution)	28
DRIFT (Zero Drift Correction)	29
<b>Communication</b>	<b>31</b>
Addressed Communication	36
Communication Speed	37
Bit	38
Parity	39
<b>Weight Calibration</b>	<b>40</b>
Gain Adjustment	42
Zero Calibration	43
Load Calibration	44
<b>Option</b>	<b>46</b>
Digital Output	46
Relay output (OUT-0)	48
Binary / BCD Output	50
BCD Output (OUT-1)	52
Binary Output (2's complement) (OUT-2)	53
<b>Analog Output</b>	<b>55</b>
Adjustment Of Analog Output	55
DAC Mode	56
Analog Output Adjustment (DACCAL)	58

<b>PWI Program Selection</b>	<b>64</b>
<b>Weight Measurement</b>	<b>65</b>
<b>Resetting Display Value To Zero</b>	<b>65</b>
<b>Activating Tare</b>	<b>66</b>
<b>Showing Tare Value</b>	<b>66</b>
Disabling Tare Value	67
<b>Level Control</b>	<b>67</b>
Transmitting Weight Value From Serial Line	71
<b>PWI Peak-Hold Indicator Program</b>	<b>71</b>
<b>PWI Bag Filling Program</b>	<b>76</b>
<b>PWI Batch Controller Program</b>	<b>80</b>
<b>Power Supply Controller Program</b>	<b>86</b>
<b>Operating Temperature</b>	<b>86</b>
<b>Cable Connections</b>	<b>87</b>
<b>Loadcell Connection</b>	<b>88</b>
<b>Communication Cables</b>	<b>90</b>
<b>Error Codes</b>	<b>91</b>

# Intruduction

PWI Indicator is designed for fast, accurate and high sensitive weight, force and pressure indication. The indicator can be used with every kind of resistive bridge sensors.

The indicator was designed for industrial applications and standard weight measurement fields. The communication with commonly used PLC's has been taken into account, where they are widely used almost in all the automation systems. Besides the computer and PLC communication features, the indicator is also suitable for tank weighing, platform scales and batching systems.

PWI possesses custom designed Liquid Crystal Display for easy operator dialogue. With the red light LED option of the display, weight can easily be seen even in the dark environment. The special characters on the display enables the user to be familiar with the keypad and universal weight and measure icons. The analogue bar graph makes the weight to be easily understandable by showing the weight in percentage of the full scale. It possesses a water and dust proof membrane keypad. All calibration values can be set via this keypad (calibration, span adjustment, communication mode, parameters, etc.). Designed with SMD technology.

# PWI Series Indicators

## Available Outputs

### **Relay Output**

4 In / 8 Output

### **Analog Output**

Voltage Output (0-10 V)

Current Output (0-20 mA)

### **BCD / BIN**

1+18 bit Output

### **Serial Data Out**

1200bps, 2400bps

4800bps,9600bps



# Specifications

## Technical Specifications

- Easily achieved menu steps
- Parameter and calibration changes easily done via keypad
- Connectable upto  $\pm 10$  mV/V input ( $\pm 100$  mV)
- Sense-Gain adjustment according to sensor output
- Tare function enabling zeroing within whole weighing range
- 250mA at 10 VDC loadcell excitation voltage
- 90/384 EEC EURO directives and CE approved
- Test of all functions during power up

## Operating Specifications

- Following functions can be fulfilled via keypad
  - Calibration
  - Gain adjustment
  - Communication format and speed
  - Digital signal filter
  - Taring
  - Displaying tare
  - Zeroing
- Displaying excitation and output signals of the sensor
- No-motion detection
- Center of zero detection (1/4 d)
- Warning above maximum allowable weight

## Display Specifications

- └ Specially designed wide viewing-angle LCD or LED display
  - └ Analogue bar-graph (LCD display)
  - └ 7 digital output symbol
  - └ 2 digital input symbol
  - └ Tare indication
  - └ Center-of-zero symbol
  - └ No-motion detection symbol
  - └ Up-down and equal symbols (LCD display)
- └ Showing weight with decimal point (236.910 kg)

## Control Specifications (Options)



- └ 18+1 Bit BCD or Binary
- └ 0-10 V or 4-20 mA analogue output
- └ Control. Formed of 8 outputs, 4 inputs

## PWI Series Indicators

Input	: DC: -100.00 ,+ 100.00 mV
A/D speed (/second)	: 50
Display sensitivity	:1/100.000
Display	: LCD or 7-segment LED
Maximum range	: 6 digit (-199999 +999999)
Communication	: RS-232C/RS-485/RS-422
Loadcell excitation	: 250 mA @10 VDC (8 Load cells)
Input voltage	: 12-24 V DC or AC
Weighing accuracy	: 3000d or 5000d class III model
Additional specifications	: Special software available
EMC	: EN 55011:1991 Emission - Class A EN 45501:1992 Metrological aspects of non-automatic weighing instruments EN 50082:1995 Generic immunity standard, from which: EN 61000-4-2:1995 Electrostatic discharge (ESD) immunity ENV 50204:1995 Digital radio telephones immunity EN 61000-4-4:1995 Electrical Fast Transient (EFT) immunity EN 61000-4-6:1996 Conducted Radio-Frequency disturbances immunity

# Physical Dimensions





## PWI-P (Panel Type)





Dimension-Cut Out:137.5x67.5mm

# PWI Series Indicators



## PWI-D (Desk Type) - PWI-C (Column Type)






## PWI-S (Stainless Steel Type)



## PWI-E (Ex-proof Type)




## PWI-T / X (Weighing Terminal)





# Apperance

## LCD Display



1- Tare

2- Up

3- Equal

4- Down

5- Center of Zero

6- No Motion

7- Set-Point

8- Inputs

9- Kg

10- Analog Bargraph

11- Test

12- Zeroing

13- Tare

14- Tare Show

15- Set-Point

16- Print

## Annunciators



Tare : Lights when TARE is active. Blinks when showing the TARE weight.




No motion indication: Lights when there is no motion and goes off when there is movement on the platform.



Center of zero: Lights when displayed weight is zero and the internal count is less than  $1/4d$  ( $d$ : The internal count which can increase the display by 1 step value).

## Scale Type LED Display



1-Zero: Center of Zero

2- e1: 1. Step


3- e2: 2. Step

4- Max: Max. Load

5-Tare

6- No Motion

## Standard Panel Type LED Display



1- 4 Outputs

2- Tare

3- No Motion

# Keys



**Test Key:** Tests all functions. Device acts as if first powered-up.



**Zeroise Key:** Makes screen value 0 (zero) if within allowable limits.



**Tare Key:** Used to set value as TARE or disable the previous tare value. Works as toggle uses as MOVE CURSOR in parameter entries.



**Show Tare Key:** Displays tare value when TARE is active, used as INCREMENT in setup mode.




**Set-Point Key:** Used for entering menus for set-up and calibration.



**Print Key:** Transmits the serial data of the weight value from the serial out. In setup mode used as ENTER.

## Assembling The PWI Indicator



- 1- Analog output 15'd female
- 2- Digital output 25'd male
- 3- LC connector 9'd female
- 4- Communication connector 9'd male
- 5- Power connector

The indicator is taken out from its protecting case. The Loadcell cable and Serial communication cables are connected to Loadcell connector and serial communication connector respectively.

If the PWI indicator will not be connected to an external device (PC, PLC) then serial output connector is left unplugged.

The power supply given together with the indicator or a similar which fulfills the power conditions is connected to the power connector.





## PWI Series Indicators

When energy is applied from the power connector, the device starts working with the TEST procedure ( Page: 18).

Since analog output, 0(4)-20mA or 0-10V; digital output are optional, they do not exist on a standard device. The user must state the necessary options before demanding the device. **The user needs an external power supply of 18-24 VDC for 0(4)-20 mA or 0-10 V analog output option.**

If cable connections will be done by your side see Page: 88 for connections.

# Safety Precautions

- Always use the power supply given together with the indicator or a similar one with specifications given in (Page: 86).
- Never press the keys with sharp or cutting edged materials. 
- Take care that load cell or power cables do not pass near power or transmission lines. 
- Keep cables away from bruises. 
- Take care of the operating temperature ( Page: 86). 
- After all connections are completed, apply energy to the indicator. Never make changes in connections when power is on.

## Basic Flow of PWI Indicator

8.8.8.8.8.8.

SP ?

-----

SP ?

VER-4.3

SP ?

Stndrd

SP ?


ESIT


SP ?

10.000 kg

SP ?

WEIGHING

When power is first applied or  **TEST** key is pressed, all segments of display are lit.

Before normal weighing display, by pressing the set-point key  **SET-UP** and **CALIBRATION** routines can be executed.

 >>> **SET-UP** Power-up screens are as follows:

**VER-4.3:** Number of the software version  
**PROGRAM TYPE**

STNDRD: Standard

PWI-T: Truck Scale

FILLNG: Filling-Batching

DOSAGE: Dosage Batching

HOLD: Peak and Hold


AXLE: Static/Dynamic axle scale

**ESIT:** Manufacturer company



**CHECK-SUM** Program control code

**CAPACITY:** Maximum allowable weight





# Parameters



After power is first applied or  TEST key is pressed, by simply pressing the  SET-POINT key, the PARAMETER menus can be executed. These menus are formed in six main groups: **LCTEST**, **SETUP**, **COMM**, **CALIBR**, **OPTION** and **DACCAL**.

## Load Cell Test

Within this menu, the value of the analog input is displayed. The millivolt calibration of the indicator is factory set and cannot be changed later. The maximum input range of the analog input is  $\pm 100\text{mV}$  ( $\pm 10\text{mV/V}$ ).

In order to enter this routine PRINT key  is pressed. To switch to the next menu, SETUP, SHOW-TARE key  is pressed.

When LCTEST menu is entered, on the right hand side of the screen appears.




To exit the menu TEST  key is pressed.

# Parameter Entry (Setup)

In this menu, Digital Filter, Decimal Point, Weighing Capacity, Weighing Steps and Drift parameters are displayed and can be changed.

In order to enter this routine, PRINT  key is pressed. To switch to next menu (COMM) SHOW TARE  key is pressed.



## PWI Series Indicators

### **FILTER MODE:**

**FILTR.0** : Speedy measurement. (Recommended for Hold Programme)

**FILTR.1** : Normal measurement. (Recommended for Standard Programme)

**FILTR.2** : Slow measurement. (Recommended for PWI-T Programme)

**FILTR.3** : Coarse filling. (Recommended for Filling Programme)

**FILTR.4** : Fine filling. (Recommended for Filling and Batching Programs)

**FILTR.5** : Custom set. User can adjust the filter parameters.

**FILTER SPAN:** Acceptable maximum changing value of screen.

**VB.TM:** Vibration time. (0.0-9.9 sec)

**BUFFER SIZE:** Average.

**BUFFR.0:** Averaged 2 sample.

**BUFFR.1:** Averaged 4 sample.

**BUFFR.2:** Averaged 8 sample.

**BUFFR.3:** Averaged 16 sample.

**BUFFR.4:** Averaged 32 sample.

**CERTF:** (1) shows whether the indicator is dependent on the regulation of weighing authorities.

If CERTF=1, do not allowed DRIFT and zeroing if over %2 of the capacity.



**BG.ZRO:** (1) If the screen value less than %20 of the capacity, can be automatically zeroed at the power up. (beginning of the weighing)


## Decimal Point

When the display resolution needs decimal point for fractional values, it is possible to show it on the display.



The value next to DOT is the number of digits on the right of decimal point. It blinks to show it is being edited.

If the value on the display is accepted, PRINT  key; to increase the value, SHOW TARE  key is pressed. The allowable values are: **0, 1, 2, 3.**



### Scale Type

The indicator may be configured with two weighing ranges with two different weighing resolutions to enable higher accuracy readings in lower values.

There are three different modes to select from:





- └ Single interval
- └ Multi-interval
- └ Multi-range

In single interval mode, there is only one range and one resolution; in the others there are two ranges and resolutions.

## *CAP-2* (Maximum Allowable Weight)


This value determines the maximum weighing range of the indicator. The indicator will produce an error code when the weight value on the platform exceeds **CAP2+9e<sub>2</sub>** value.

When this routine is first entered, on the display **CAP2** text is seen for a second and leaves the display to its numeric value. The left-most digit on the display starts blinking showing which digit may be edited.

In order to increase the digit that is blinking, SHOW TARE key  is pressed. To pass the blinking digit to next digit, TARE key  is pressed. To reduce the value down to 0 in a single step, ZEROISE key  is pressed. To save the value in the memory, PRINT key  is used.



## **e<sub>2</sub>(Weighing Display Resolution)**

This parameter shows the weighing steps after the weight on the display exceeds the multi-interval point. The step value may be **1, 2, 5, 10, 20** or **50**. The user must select an appropriate value in accordance with the CAPACITY.



<b>CAP-2</b>	<b>e<sub>2</sub></b>
Up to <b>3 000 kg</b>	<b>01 kg</b>
<b>3 000 - 6000 kg</b>	<b>02 kg</b>
<b>6000 - 15 000 kg</b>	<b>05 kg</b>
<b>15 000 - 30 000 kg</b>	<b>10 kg</b>
<b>30 000 - 60 000 kg</b>	<b>20 kg</b>
More than <b>60 000 kg</b>	<b>50 kg</b>

### **Weighing steps $\geq$ (Capacity / 3000)**

In order to change the WEIGHING STEP value; SHOW TARE key  is pressed.  
To save the value in the memory, PRINT key  is used.







## *CAP-E1*(First Interval)

The PWI indicator is capable of using 2 different weighing step values in two intervals. That is to say, the indicator will show the weight with small weighing steps with lighter weight and with bigger weighing steps when the load increases. The point where the weighing steps change is **CAP1**(the multi interval point).

If the maximum allowable weight is 60.000 kg and the weighing steps is 20 kg, the operator may adjust the PWI indicator to show the weights in 10 kg steps until 30.000 kg. For this, the following parameter adjustment must be done


<b>CAP-2</b>	<b>60 000 kg</b>
<b>e<sub>2</sub></b>	<b>20 kg</b>
<b>CAP-1</b>	<b>30 000 kg</b>
<b>e<sub>1</sub></b>	<b>10 kg</b>

When this routine is first entered, on the display **CAP-E1** is seen for a second and leaves the display to the numeric value. The left-most digit on the display starts blinking, showing which digit may be edited.

In order to increase the digit that is blinking; SHOW TARE key  is pressed. To pass the blinking digit to next digit, TARE key  is pressed. To reduce the value down to 0 in a single step, ZEROISE key  is pressed. To save the value in the memory, PRINT key  is used.

### **e<sub>1</sub> (Weighing Steps Display Resolution)**

This parameter shows the weighing steps before the weight on the display exceeds the multi-interval point. The step value may be **1, 2, 5, 10, 20** and **50**. The user must select an appropriate value in accordance with the CAPACITY.



**(CAP-1)**

Up to **3000 kg**

**3000 - 6000 kg**

**6000 - 15 000 kg**

**15 000 - 30 000 kg**

**30 000 - 60 000 kg**

Above **60 000 kg**

**(e1)**

**01 kg**

**02 kg**



**05 kg**

**10 kg**


**20 kg**

**50 kg**

#### **Weighing steps $\geq$ (Capacity / 3000)**

In order to change the WEIGHING STEP value; SHOW TARE key  is pressed.  
To save the value in the memory, PRINT key  is used.


The weighing step resolution can be seen on SCALE type PWI indicators.



## ***DRIFT* (Zero Drift Correction)**


Zero drift correction parameter is designed to counter the effects of rain, snow or dirt collecting on the platform, which would otherwise cause cumulative errors. When enabled, the zero condition is maintained for very slow, small changes occurring in the measured weight of the platform, as long as the changes are within the usual half of the weighing steps deviating from the true zero value.



Note: This mode may be in contravention of some Weight & Measures Authorities Regulations, therefore should be set to 0.


Since this zeroing is not stored in the non-volatile memory like the calibration zero or the user zero, unplugging the indicator or pressing the TEST key  will bring back the last key-pressed zero value. If the operator wishes to enable this feature, then DRIFT variable should be set as 1 otherwise as 0.

During the time TARE is active, DRIFT feature is disabled.

## PWI Series Indicators



In order to toggle the DRIFT value, SHOW TARE  key is pressed. To save the value in the memory, PRINT  key is used.



Drift automatically readjusts the scale to zero for compensating selected small deviation per 2 second around center of zero.

1=0,5e

2=2e

3=3e

4=4e

5=5e


6=6e

7=7e

8=8e

9=9e

# Communication Parameters (COMM)




If the hardware of the indicator possesses serial transmission feature, the parameters should be set according to the device, i.e. PC or PLC, which will communicate with the PWI indicator. The indicator is produced according to the demand from the user in one of the following serial transmission standards.



## PWI Series Indicators

RS-232

RS-485

RS-422



The value next to MODE shows the communication mode. If the value on the display is accepted, PRINT  key; to increase the value, SHOW TARE  key is pressed. The allowable values are: 0, 1, 2, 3, 4.

**MODE 0** —● No communication

**MODE 1** —● Continuous transmission of 6-digit weight value

**MODE 2** —● Continuous transmission of weight, tare and status

**MODE 3** —● Addressed communication mode 6 digit weight value


**MODE 4** —● For axle scale

**MODE 5** —● MODBUS

**MODE 6** —● Hold mode

**MODE 7** —● Transferred barcode (read from serial barcode reader) with weight value.

**MODE 8** —● Designed for Esit FIXUM indicator communication format.

**MODE 0:** Disables communication feature. In this mode PRINT  key is not enabled and protocol bits are not edited.

**MODE1:** The indicator transmits the weight value in continuous mode with the following format. The data consists of 8 bytes.

## Display

<b>31249 kg</b>	'+'	'0'	'3'	'1'	'2'	'4'	'9'	CR
HEX	2B	30	33	31	32	34	39	0D

<b>-5780 kg</b>	'.'	'0'	'0'	'5'	'7'	'8'	'0'	CR
HEX	2D	30	30	35	37	38	30	0D

<b>1.600 kg</b>	'+'	'0'	'0'	'1.'	'6'	'0'	'0'	CR
HEX	2B	30	30	B1	36	30	30	0D



<u>Character</u>	<u>HEX</u>		<u>Character</u>	<u>HEX</u>	
0.	B0	(30+80)	5.	B5	(35+80)
1.	B1	(31+80)	6.	B6	(36+80)
2.	B2	(32+80)	7.	B7	(37+80)
3.	B3	(33+80)	8.	B8	(38+80)
4.	B4	(34+80)	9.	B9	(39+80)

**CODE:** 0 → If there is a decimal point on the display, then the corresponding digit is sent with hex80 added to the ASCII value.


1 → Sent "." 2E (HEX)

# PWI Series Indicators

**MODE- 2** : For a more detailed data this communication mode is selected. Within the data, STATUS, DISPLAY value and TARE value are sent. The data consist of 18 bytes.



STX SW1 SW2 SW3 0 1 2 9 6 5 0 0 0 0 0 0 CR CHX  
 02 2D 30 20 30 31 32 39 36 35 30 30 30 30 30 0D XX





This is a standard format used in most of the weighing indicators. The DATA for a system with Tare value is 1250 kg, Weighing Steps is 1, Decimal point 0 is as follows: (7 bits)

**Display**


31249 kg

**WEIGHT**


0, 3, 1, 2, 4, 9, 0, 0, 1, 2, 5, 0, CR, CHX

**TARE**

HEX 02, 3D, 20, 30, 33, 31, 32, 34, 39, 30, 30, 31, 32, 35, 30, 0D, BB


**MODE 3:** The communication of weight value is performed when the indicator realizes the code from the other side. By this way; more than one indicator can be connected to the, same communication line. The data format is same as **MODE1**, the only difference is that the data is transmitted only when demanded from serial line or by pressing PRINT  key.


In this mode, when pressing the PRINT  key, the same data is transmitted as if the code was received. ( Page: 29 )







For a PC to communicate with more than one indicator, this parameter should be set to MODE 3, and the communication hardware should be RS-422 or RS-485.

### Addressed Communication

After MODE 3-MODE 5 is selected and PRINT  key is pressed, the indicator will be waiting for its address.



When first entered the right-hand digit next to Adr starts blinking.

increase the digit value of the blinking digit, SHOW TARE  key; to pass to next digit, TARE  key; to set the blinking value to zero, ZEROISE  key; to accept the whole value, PRINT  key should be pressed.

In order to communicate with a PWI indicator, the PC or the PLC should first transmit a WAKE-UP code (HEX FF), followed by the address given with this parameter.

**Example:** If Adr is set as 31 the indicator will send the weight data after receiving



	(Wake up)	'1'
HEX	(FF) <sub>h</sub>	(31) <sub>h</sub>


If the address is set to 00 then the indicator will send the weight data after receiving any character from the serial receive line. The Address may take any value from **00** to **99** (the value is hexadecimal).

When more than one PWI indicators are connected to the same transmission line, then the devices should have RS422 or RS 485 communication hardware and all should have **unique addresses**.

## Communication Speed

The number of communication bits sent per second is called BAUDRATE. The selectable values are: 1200, 2400, 4800, 9600.

If the value on the display is accepted, PRINT  key; to increase the value, SHOW TARE  key is pressed.




# PWI Series Indicators

## Bit

This parameter gives the number of bits in a communication byte.

When first entered the right-hand digit next to BIT starts blinking.

To switch between 7 to 8, SHOW TARE  key is pressed. After necessary change is done or if the value is accepted, PRINT  key is pressed.





The ASCII code for character 'A' is hexadecimal 41. This is shown as:

	<u>7</u>	<u>6</u>	<u>5</u>	<u>4</u>	<u>3</u>	<u>2</u>	<u>1</u>	<u>0</u>
7 bit	x	1	0	0	0	0	0	1
8 bit	0	1	0	0	0	0	0	1

With 7 bit 128 (hex 7F), and 8 bit 256 (hex FF) different characters can be coded.


## Parity

This parameter is used for transmission data control purposes. This is in fact a control bit within a character. It can be set as NO, ODD or EVEN

If the value on the display is accepted, PRINT  key; to change the value, SHOWTARE  key is pressed.




PR. EVEN



# Weight Calibration

PWI indicator should be calibrated with a known weight. Before starting the calibration procedure, the following points should be kept in mind.



The indicator should be kept in power for about ten minutes before starting the calibration procedure. 



If possible, during this wait time, load and unload the weight for a few times.




Keep away all obstacles that may prevent load to be sensed by the platform.





The calibration weight should better be approved by authorities.

The reference weight should better be at least half of the capacity.





## Gain Adjustment

When CALIBR is seen on the display by pressing the PRINT  key, Gain Adjustment step can be performed. This adjustment should be done according to the output of the analogue signal. When it is set correctly, the indicator will have better performance.



When first entered the right-hand digit next to LC starts blinking.

If the value on the display is accepted, PRINT  key; to increase the value, SHOW TARE  key is pressed.

<u>Analog Input (mV/V)</u>	<u>Gain</u>
between 0.1 - 1.1	—● 1.25
between 1.1 - 2.2	—● 2.50
between 2.2 - 4.5	—● 5.00
between 4.5 - 9.9	—● 10.0

When GAIN selection is done, the value should be set as the nearest higher output value given in the above table.





## Zero Calibration

In order to introduce the empty platform value to the device, **Zero Calibration** should be performed. For a short time **ZERO** is seen on the display.



Then it leaves to the internal count value.




After the platform is emptied, ZEROISE  key is pressed. The internal count value will be reduced to a value around zero. If the previously entered “Zero Calibration” is not to be changed, the operator should press PRINT  key to pass to the next step, the **CALIBRATION**.



### Load Calibration





To introduce the value of the known weight **LOAD CALIBRATION** should be performed. After Zero calibration routine is exited, for a short time **LOAD** is displayed.



This message will leave the display to the internal count value.




If needed, during this time ZEROISE  key can be pressed again. The weight is placed on the platform. When the no-movement state is achieved, that is to say, the internal count value reaches stability, SETPOINT  key is pressed to enter the section where the weight of the load is written to the indicator.

In order to increase the blinking digit by one, SHOW TARE  key; to pass to next digit, TARE  key ; to make the blinking value zero, ZEROISE  key; finally to accept the written value, PRINT  key is pressed.

After the weight value is written and PRINT  key is pressed, the PWI indicator will start the TEST procedure.

GAIN is selected.



 When platform is empty,  
ZEROING is done.



Load is placed and its value is written.





## Option

### Digital Output

After CALIBR (calibration) section, MENU is performed.





This value defines the digital output. In order to define the digital output type, PRINT  key is pressed. To skip this menu and pass to (DACCAL), SHOW TARE  is used.

The digit next to OUT starts blinking. This defines the type of digital output.




- 0—● Relay Output.
- 1—● BCD Output
- 2—● Binary Output (2's complement)
- 3—● Binary Output (18 bit + sign)




If the value is accepted, PRINT  key is pressed. to change the value SHOW TARE  key is pressed to select 0, 1, 2 or 3.

**This parameter requires the OPTION board to be plugged inside the indicator. When selecting the output, check the hardware with the selection and plug the connector after verifying the system.**

## Relay Output (OUT-0)



## Relay Cable: 8 Out / 2 In




By using a PWI indicator, 7 relay output and 2 input signal can be controlled. The set-point, SP, which is activated on the display is also output simultaneously on the relay output. If on the display SP2, SP5 are lit, then on the relay output card, 2 and 5 number relays are activated. (Activation of Relay means Common pin is tied to Normally Open pin).

## Binary / BCD Output

1. → Sign	14. → D18*
2. → D17	15. → D16
3. → D15	16. → D14
4. → D13	17. → D12
5. → D11	18. → D10
6. → D9	19. → D8
7. → D7	20. → D6
8. → D5	21. → D4
9. → D3	22. → D2
10. → D1	23. → D0
11. → Vcc	24. → Vcc
12. → Input-2	25. → Input-1
13. → Gnd	

Before normal weighing mode is passed, during power-up, and on error conditions, -0 (negative zero) is output.




\* The BIN/BCD outputs PWI indicators can be configured as CONTINUOUS or ON-DEMAND by the user.

When the output should be CONTINUOUS, then pin no14 should be connected directly to Vcc (11 connected 24 pin). If the output should be ON-DEMAND, the user should supply Vcc as long as the output is needed. This is useful when more than one indicators are connected to the same input port and all are read one after each other.

As long as the pin no14 is left idle (no-connection), no output can be received from outside (open collector output).



## BCD / Binary Output



## BCD Output (OUT-1)



	12495 kg	-1780 kg	ERROR, START-UP
SIGN	0	1	1
D18*	-	-	-
D17	0	0	0
D16	1	0	0
D15	0	0	0
D14	0	0	0
D13	1	0	0
D12	0	1	0
D11	0	0	0
D10	1	1	0
D9	0	1	0
D8	0	1	0
D7	1	1	0
D6	0	0	0
D5	0	0	0
D4	1	0	0
D3	0	0	0
D2	1	0	0
D1	0	0	0
D0	1	0	0

BCD (Binary Coded Decimal)  
Output. 4½ digit (39 999 kg)  
output maximum.

## Binary Output (2's Complement) (OUT-2)



	12495 kg	-1780 kg	ERROR, START UP
SIGN	0	1	1
D18*	-	-	-
D17	0	1	0
D16	0	1	0
D15	0	1	0
D14	0	1	0
D13	1	1	0
D12	1	1	0
D11	0	1	0
D10	0	0	0
D9	0	0	0
D8	0	1	0
D7	1	0	0
D6	1	0	0
D5	0	0	0
D4	0	0	0
D3	1	1	0
D2	1	1	0
D1	1	0	0
D0	1	0	0

BINARY Output. 1(sign) + 18 bit (262.143 kg) output maximum.

## Binary Output (Absolute) (OUT-3)



	12495 kg	-1780 kg	ERROR, START-UP
SIGN	0	1	1
D18*	-	-	-
D17	0	0	0
D16	0	0	0
D15	0	0	0
D14	0	0	0
D13	1	0	0
D12	1	0	0
D11	0	0	0
D10	0	1	0
D9	0	1	0
D8	0	0	0
D7	1	1	0
D6	1	1	0
D5	0	1	0
D4	0	1	0
D3	1	0	0
D2	1	1	0
D1	1	0	0
D0	1	0	0


BINARY Output. 1(sign) + 18 bit (262.143 kg) output. The value is output without the dot value.

# Analog Output

In order to transmit the weight value that the PWI indicator reads to an external automation device with analog input, the analog output option is used.

$$\text{Analog Output Value (V) (mA)} = \frac{\text{Display Value} \times (\text{High Val.} - \text{Low Val.})}{\text{Weighing Capacity}} + \text{Low Value}$$

## Adjustment of Analog Output



**PWI indicator analog output needs an external power supply of 18-24 VDC.**


In the setup section, after OPTION, the menu for analog output adjustment is reached: DACCAL. In this menu, the zero output and maximum value analog values are adjusted.




To pass to LCTEST menu, SHOW TARE  key is pressed. To perform the analog value adjustment, PRINT  key is pressed.

## Dac Mode

This mode defines whether the Analogue output should follow the gross value (although TARE is active and NET mode is ON), or should follow the display value (NET value when TARE is on, and GROSS value otherwise)




When tared, display will be 0 and the analogue output goes down to Lo-Val value. This mode follows NET value.



When tared, display will be 0 but the analogue output will keep the value. This mode follows GROSS value.

The difference can be seen on LCD displays as follows:



When tared,




**DAC.NET**




**DAC.GRS**


DAC Mode change is done by SHOW TARE  key . To store the value, PRINT








 key is pressed

### Analog Output Adjustment (DACCAL)



This value determines the analogue output when the platform is empty.




To increase the value by 1, SHOW TARE  key is used when the right hand digit is blinking. To decrease by 1, SET-POINT  key is used. To switch between 1 by 1 and 10 by 10, TARE  key is used. Then SHOW TARE  and TARE  keys will change the values by 10. The ZEROISE  key will set the whole value down to 0. When the value is adjusted correctly, PRINT  key is used to save the value.








The value that is seen on the screen of the meter is the value that the indicator will produce when there is no load on the platform. If the user wants to use 4-20 mA, then this value should be set to 4mA (the device can output 0 to 20 mA).






Then, the upper value is adjusted. This value is the value that is produced when the weight on the platform reaches the CAPACITY value.




Just like adjusting the lower value, the same keys are used for adjusting the upper value. To increase the value by 1, SHOW TARE  key is used when the right hand digit is blinking. To decrease by 1, SET-POINT  key is used. To switch between 1 by 1 and 10 by 10, TARE  key is used. Then SHOW TARE  and TARE  keys will change the values by 10. The ZEROISE  key will set 4095. When the value is adjusted correctly, PRINT  key is used to save the value.

The value that is seen on the screen of the meter is the output that the indicator will produce when the load is equal to the MAXIMUM CAPACITY value.

## PWI Series Indicators




If the CAPACITY is set to 1000 kg, the signal from analog output is 10V, when 500 kg is seen, the value is 6V and with no load 2V is read.



If the CAPACITY is set to 5000 kg, the output from analog output is 20mA, when 1250 kg is seen, the value is 8mA and with no load 4mA is read

**In order to get the desired output, either voltage or current, the following short circuits must be done.**

**0-10V analogue output;**

**8.** + Power 18-24Vdc


**6.** - Power 18-24Vdc  
(GND)

**10-11.** + (0-10)V Output


**13-14.** - (0-10)V Output  
(GND)

- Between pins 10 and 11, should be shorted to each other
- Between pins 13 and 14, should be shorted to each other
- The 0-10V output is read between these two short circuited pins.
- 18-24V power supply is connected to 8 pin on positive pole, and to 6 pin on the negative pole.

## 4-20mA analogue output (Source mode);




- 8.** + Power 18-24Vdc
- 6.** - Power 18-24Vdc (GND)
- 1-3.** Short Circuit
- 2-10-14.** Short Circuit
- 10.** +(4-20)mA Output
- 13.** -(4-20)mA Output




- Between pins 1 and 3, should be shorted to each other
- Between pins 2-10 and 14, should be shorted to each other
- 18-24V power supply is connected to 8 pin on positive pole, and to 6 pin on the negative pole.
- The 0-20mA output is read between 10 (+4-20mA) and 13 (-4-20mA).

① If the device is to be connected has no internal resistance ( $0 \Omega$ ), then 4-20mA output is taken from pin no 12 not 13.

## 4-20mA analogue output (Sink mode);



- |                    |                        |
|--------------------|------------------------|
| 8.                 | + Power 18-24Vdc       |
| 6.                 | - Power 18-24Vdc (GND) |
| <b>2-10-13-14.</b> | Short Circuit          |
| 1.                 | + (4-20)mA Output      |
| 3.                 | - (4-20)mA Output      |



- ┌ Between pins 2-10-13 and 14, should be shorted to each other
- ┌ The 0-20mA output is read between 1 (+output) and 3 (-output).
- ┌ 18-24V power supply is connected to 8 pin on positive pole, and to 6 pin on the negative pole.

① If the device is to be connected has no internal resistance ( $0 \Omega$ ), then 2-10-14. must be short circuit. 12-13. should be short circuit.

# PWI Program Selection

PWI indicator may be configured to run software that is relevant to the application. Only the usage is different, no calibration change or correction is needed, therefore the user may change the user software without breaking the calibration seal (if exists). During order, if the usage is stated, then the program comes with the desired usage, otherwise STANDARD Program is set. Besides, during order, necessary option outputs must also be stated.


The various program selection is as follows:

- Standard
- Truck scale
- Bag filling scale
- Batching (up to 6 materials)
- Peak-Hold indication
- Axle scale

The change of the program can be learned from technical service.


## Weight Measurement

If during TEST procedure, no key is pressed, the indicator will start showing the weight on the platform. In this mode, Zeroing, Tare activating, setpoint control and weight value transfer can be performed.





### Resetting Display Value To Zero

To reset the weight value to zero, ZEROISE **↔0↔** key is pressed. In order to perform this function, the indicator should be in no-movement state which can be realized with the symbol is lit and TARE should be not active.




After ZEROISE **↔0↔** key is pressed, the value turns to zero and center-of-zero **↔0↔** (LCD) - o (LED) symbol is lit. This may happen only if the value is within user resettable value.


## Activating Tare



If the NET mode is desired, TARE function should be activated by pressing the TARE  key. When there is movement, i.e. the  symbol is not on, this key is ignored.



When tare is activated, the display will be zero and Tare symbol is lit. In order to TARE a value, the weight on the platform must be positive. When TARE is active, ZEROISE  key and function are disabled.

## Showing Tare Value

When TARE is active, the operator can see the Tare value as long as the SHOW TARE  key is pressed.




To show that the value displayed is the tare value the TARE symbol blinks.







## Disabling Tare Value

When tare is active, pressing the TARE  key again, will disable the TARE function and the gross weight on the platform is displayed, that is to say, the device is in the GROSS mode. The TARE symbol goes off.






## Level Control

PWI Indicator possesses 7 digital set-point indication on the display. These are used to warn the operator whether the value is under or over the desired set values. In order to enter these set values SET-POINT  key is pressed for 3 seconds.




On the display  symbol and SET1 is displayed. The 0 or 1 on the right hand side can be changed by pressing SHOW TARE  key. The symbols UP and DOWN are lit according to this value. If the value is 0 and the DOWN symbol is lit, during weight measurement, the related set-point indicator will be active if the value is less than the set point. If the value is 1 and the UP symbol is lit, during weight measurement, the related set-point indicator will be active if the value is more than the set point.

## PWI Series Indicators

When the UP or DOWN is set PRINT  key is pressed to pass to value display/edit section. The rightmost digit starts blinking. To increase the digit value of the blinking digit, SHOW TARE  key; to pass to next digit, TARE  key; to set the blinking value to zero, ZEROISE  key; to accept the whole value, PRINT  key should be pressed.



After all set-points are defined, SET-POINT  key is pressed, all values stored in the memory and weight display mode is returned.


### EXAMPLE:



Setting the set-point values with the following values:






**SP1** Active when weight is more than 1.000 kg



**SP3** Active when weight is less than 1.700 kg



All others ( **SP2** **SP4** **SP5** **SP6** **SP7** ) are not lit.

Press SET-POINT  key during weight measurement routine, for three seconds.



By pressing SHOW TARE  key, set the blinking value to 1. Press the PRINT key to pass to value entry part. Pressing the TARE  key come to the third digit. Press the SHOW TARE  key to make the value 1. When the value is set to the desired value, here 1.000, press the PRINT  key to accept it. At this point on the screen **SP2** symbol and SET2- are seen. In order to come to the setpoint-7, press the TARE  key five more times.



Set the SET-3-value to 0 with the help of TARE  key. After pressing the PRINT  key set the value to 1.700 kg as explained above. The other values should be set as below.

**SET-2-0 000.000 kg **SP2****


**SET-4-0 000.000 kg **SP4****



**SET-5-0 000.000 kg **SP5****

**SET-6-0 000.000 kg **SP6****

**SET-7-0 000.000 kg **SP7****



## PWI Series Indicators

After setting all set-point variables press SET-POINT  key . When weight is on the display you will see that above 1.000 kg **SP1** , below 1.700 kg **SP3** will lit.




**SP1** OFF 1st relay out is passive,

**SP3** ON 3rd relay out is active.



**SP1** ON 1st relay out is active,



**SP3** ON 3rd relay out is active.




**SP1** ON 1st relay out is active,

**SP3** OFF 3rd relay out is passive.

## Transmitting Weight Value From Serial Line


If in the SET-UP part, the parameter MODE 3 was set, the weight value can be transmitted by pressing the PRINT  key from the serial line. In order to transmit the data, no-movement state must be achieved (On the display, symbol  must be ON)






## PWI Peak Hold Indicator Program


The program which determines the weight at the breaking point of a material under stress or strain is called the PEAK/HOLD indicator program. When this program is used, the operator must state the value for sensing the real break point. The peak point can be found by the sudden fall of the weight value coming from the load cell. Normally, there may be a small drift where the material is not broken but is loosened. In order the device to understand that the weight decrease is due to material break but not the loosening, the operator should enter the SPHOLD value


## PWI Series Indicators



Using this feature (after the program is set as HOLD, SHOW-TARE key  is pressed. On the display HOLD is seen for a second to show that the mode is changed from normal weighing mode to Peak/Hold mode. When the weight value that has been displayed




drops more than the value stated by the operator, DOWN () symbol is lit and the maximum value is kept on the display (although the weight is reduced).

The value on the display may change if the weight value exceeds this value or PRINT  key is pressed or Input 2 is activated from outside.

Disabling this mode, SHOW-TARE key  is pressed or Input 1 is activated from outside.

When normal mode is returned, Up and DOWN (↓) symbols are ceased from the display.

**INPUT-2:**   
**INPUT-1:** 



**Output-4:** When the display is negative, NEGMAX value is exceeded


**Output-3:** When the value was negative, a PEAK/HOLD indication took place


**Output-2:** When the display is positive, POSMAX value is exceeded





**Output-1:** When the display is positive, a PEAK/HOLD indication took place


During HOLD mode, TARING, ZEROING and SET-POINT Change keys are non-functional

### Setting SPHOLD Value


When the PWI indicator is in normal weighing mode, SET-POINT  key is pressed for 3 seconds. The value which shows that the material under test has been broken, is entered. The system works by taking the difference between two consecutive readings and the Peak/Hold indication takes place if the difference exceeds this value.



The rightmost digit starts blinking. To increase the digit value of the blinking digit, SHOW TARE  key; to pass to next digit, TARE  key; to set the blinking value to zero, ZEROISE  key; to accept the whole value, PRINT  key should be pressed.

After the value is stored, press SET-POINT key  to return back to weighing display mode.






To show this with an example, If the break point of a material is 500kg and around about 300kg a loosening of 15kg is seen, the operator should enter a SPHOLD value a little above this 15kg.


To keep the system safe, if the material does not break or some other situation may cause the weight value increase without control, then POSMAX and NEGMAX values are checked and if these values are exceeded, Output-4 and Output-2 are activated respectively.




The user may disable or enable the kg symbol on the display by the UNIT parameter in the SET-UP menu.

### PWI BAG-Filling Program


This program is used for filling single material at the desired amount. The bag-filling process takes place by using the variables set such as filling value, delays, filling modes. When the PWI indicator is in normal weighing mode, SET-POINT  key is pressed for 3 seconds.





# PWI Series Indicators

**INPUT 2:** STOP filling  
**INPUT 1:** START filling






**Output 4:** End of filling

**Output 3:** Hold the bag

**Output 2:** Slow (fine) filling

**Output 1:** Fast (Coarse) filling





In order to use relay outputs, OPTION should be set OUT-0 in the set-up menu

## FAST:1 MOD.NET

The communication format is different for filling program

STATU. 1

STATU variable comes to the set-up menu during COMM menu if MODE is set as 2. If STATU is set to 0, then SW3 is sent as

(20)hex, if set to 1, then SW3 varies with the filling status:


SW3:

- 0: Start is waited
- 1: 1st delay time is being wait.
- 2: Fast filling
- 3: Slow filling
- 4: Filling is finished
- 5: Erroneous filling. Target exceeded Lo-VAL or Hi-VAL
- 6. Emptying process is finished

### PWI Batch Controller Program



With this program, PWI can batch up to 6 different material into the weighing bin.

### How to set the batching values

When the PWI indicator is in normal weighing mode, SET-POINT  key is pressed for 3 seconds. In this menu, 6 different batching values can be set. The outputs which are not wanted should be set as SETx-0.

Example: We want to activate the first material for 100.0kg, third material for 50.0kg and sixth material for 200.0kg and all others (2nd, 4th, and 5th) not activated at all, and give an emptying signal (from 7th relay output) until the platform weight value drops below 10.0 kg (because some material may stuck in the platform and cannot be emptied totally), and also set the delays between activating the relays one after each other with a 3 seconds delay.

Relay no	Function	Value
SET1	↑	100.0
SET2	↓	XXX
SET3	↑	50.0
SET4	↓	XXX
SET5	↓	XXX
SET6	↑	200.0
SET7	X	10.0
DELAY	-	3

Using the SHOW TARE  key, relay can be set as 1 (↑) for “will be activated” (0 (↓) for “will not be activated). Storing is done with the PRINT  key to accept. If the relay is set as 1, then the value for that relay to stay activated can be entered. Then the following adjustments should be done for the above mentioned example:

**XXX:** If the value is set as 0 ↓ then there is no need to define this value.

**End-of-batch:** After all selected relays are activated one after each other, and delays are executed, the 7th relay is activated. This output is used for emptying the platform.

**Delays:** The time needed to be waited between de-activating a relay and activating the consecutive one. Can be set from 0 to 9. It is better to set it non-zero.

**Start and Stop commands:** Input-1 gives the START signal, Input-2 works as the STOP signal.

### **Theory of Operation:**

When the PWI is in normal weighing mode, Input-1 will start the batching process. The weight on the display is set as TARE value temporarily. According to the above example, the first relay is activated until 100.0 kg is reached. At this point, relay #1 is de-activated and a delay is waited for 3 seconds. Later, the display value is again set as TARE temporarily and relay #3 is activated. Until the screen value is reached 50.0kg, the current situation is kept. At this point, relay #3 is de-activated and a delay is waited for 3 seconds. Next, the display value is again set as TARE temporarily and relay #6 is activated until the screen value is reached 200.0kg. Finally after the 3 seconds delay, the indicator activates the 7th relay for emptying purposes and the screen value turns to GROSS mode showing total material weight. The 7th relay is kept activated until the weight


## PWI Series Indicators

value drops below 10.0kg, which is assumed to be the empty platform.

The indicator, now, is ready for receiving a new START input from input1.

During the above mentioned steps, if Input2 is seen, the indicator stops every process and starts showing the real platform value (TARE is disabled) and waits the Input1 for a new process.





**INPUT 2:** STOP filling  
**INPUT 1:** START filling

**Output 8:** Normal weighing mode  
 (no errors)

**Output-7:** End of batch

**Output-6:**

**Output-5:**

**Output-4:**

**Output-3:**

**Output-2:**

**Output-1:**

## PWI Series Indicators


The serial communication format has some minor changes for the batch controller program.

STATU variable comes to the SET-UP menu during COMM menu if MODE is set as 2. If STATU is set to 0, then SW3 is sent as (20)hex, if set to 1, then SW3 varies with the filling status:



### SW3

- 0- Start is waited
- 1- Delay time for the first output
- 2- 1st output is activated
- 3- Delay time for the second output
- 4- 2nd output is activated
- 5- Delay time for the third output
- 6- 3rd output is activated
- 7- Delay time for the fourth output
- 8- 4th output is activated.
- 9- Delay time for the fifth output
- 10- 5th output is activated.
- 11- Delay time for the sixth output
- 12- 6th output is activated.
- 13- Delay time for the end-of-batch output
- 14- The end-of-batch output is given



## Power Supply Specifications

	<b>V</b>	<b>A</b>
1	12 V	1A
2	24 V	0,5A


For PWI indicator use one of the specified power supplies. Isolation voltage minimum 2000 V.

## Operating Temperature


0-50°C

# Cable Connections

Pins 1,2 and 6 should be shorted to each other, on the Load cell connector.



## Internal 2 Set Relay



# Loadcell Connection

In a Load Cell cable there exist minimum 2 internal cables for excitation and 2 for output. The colors for ESIT load cells and their meanings are given below:

### 6 internal cable type Load cell cable connection

1 pin	Blendage	Blendage (Shield)	} Short circuit to each other on the connector
2 pin	Blendage	Blendage (Shield)	
6 pin	Blendage	Blendage (Shield)	
7 pin	Red	- Output	
3 pin	White	+ Output	
4 pin	Black	- Excitation, (Input)	
5 pin	Green	+ Excitation, (Input)	
8 pin	Orange	- Sense	
9 pin	Blue	+ Sense	

The cables for connecting to the indicator can be either 6 or 4 wire cables. In a 4-wire cable, since Orange and blue do not exist, the SENSE pins should be short-circuited on the connector to the EXCITATION pins with respect to polarity.

If the system consists of more than one load cell, then a junction box is used for gathering the load cell outputs to the indicator.


After checking the correct connection is supplied, plug the load cell connector to the back of the indicator.

## 4 wire cables;


1 pin	Blendage	Blendage (Shield)	} Short circuit to each other on the connector
2 pin	Blendage	Blendage (Shield)	
6 pin	Blendage	Blendage (Shield)	
7 pin	Red	- Out	
3 pin	White	+ Out	
4,8 pin	Black	- Excitation, - Input	
5,9 pin	Green	+ Excitation, + Input	

# Communication Cables


## **PWI Communication connector (RS-232 standard);**



## **PWI Communication connector (RS-485 standard);**



## **PWI Communication connector (RS-422 standard);**





# Error Codes

During weight measurement, the PWI indicator produces some error codes in some cases. These codes and their probable reasons are as follows:

**Err-00** No Load-cell.

Check analogue signal connection. Short circuit pins 1-2-6.

**Err-01** Over range.

10e2 more than the capacity.

**Err-02** Under range.

Negative value 10e2 less than the capacity.

**Err-03** Weight too much to reset to zero in this mode.

Use Zero Calibration to reset the value.

**Err-05** Internal count overflow.

Check the GAIN value.

**Err-19** Calibration Error.

Calibration value should not be '000000'.

## PWI Series Indicators

**Err-22** Non-volatile memory error  
Call service

**Err-50** CALIBRATION not allowed.  
Calibration plug is needed.

**Err-90** Analogue value cannot be read.  
Call Service.

