


## RS232 To Ethernet module

USR-TCP232-2  
Hard version: V1.0  
File version: V1.0  
2011-11-12



Notice: USR-TCP232-2 is a base version of USR-TCP232-24, the difference from USR-TCP232-24 is no RS485 interface, the usage is same, so please look at the USR-TCP232-24 data sheet.

The interface near RJ45 is for Power Input, and also can put a USB B port here.

## 1. USR-TCP232-2 jumper

Connect Pin1 and Pin2 is for CFG, and Pin3 and Pin4 for UPD, Pin1 and Pin3 is GND, be default the jump is connect them, not any function, just put a jump here.

