


SCHEMATIC DIAGRAM - 5

B

DVD MODULE 2 (DV1) CIRCUIT


: +B SIGNAL LINE



SCHEMATIC DIAGRAM - 6**B DVD MODULE 2 (DV1) CIRCUIT**

: CD-DA SIGNAL LINE

: +B SIGNAL LINE



SCHEMATIC DIAGRAM - 7


B DVD MODULE 2 (DV1) CIRCUIT

: CD-DA SIGNAL LINE

— : +B SIGNAL LINE

: DVD (AUDIO) SIGNAL LINE


: DVD (VIDEO) SIGNAL LINE



SCHEMATIC DIAGRAM - 8

B DVD MODULE 2 (DV1) CIRCUIT

+B SIGNAL LINE

IC3051
C3ABPJ000017
64M SDRAM