


SCHEMATIC DIAGRAM - 12

B DVD MODULE (2) (AUDIO DAC) CIRCUIT

— : +B SIGNAL LINE

 : MAIN SIGNAL LINE
 : DVD AUDIO SIGNAL LINE


SCHEMATIC DIAGRAM - 13

B DVD MODULE (2) (AUDIO DAC) CIRCUIT

: +B SIGNAL LINE

: MAIN SIGNAL LINE

FL4201
F1H0J1050018LB4215
J0JCC0000119

TC4218

LB4214
J0JCC0000119

TC4217

TC4216

LB4212

TC4213

LB4211

TC4212

LB4210

TC4211

LB4209

TC4210

LB4208

TC4209

LB4207

TC4208

LB4207-LB4212
J0JCC0000119

TC4220

DV1 25BSY (AC3H)

DV1 AMUT

HIND CMD-MINI

HIND STATUS-MINI

HIND DSPCLK-MINI

DV1 AUDIODIGITAL

TC4214

TC4219

TC4282

TC4283

TC4284

TC4285

TC4286

TC4287

TC4288

TC4289

AC3H/DACMUT

AMUT

ZFLAG

DGND

CMD

STATUS

DSPCLK

DGND

AUDIODIGITAL

FP4202

C
TO
MAIN CIRCUIT
(CN303) ON
SCHEMATIC
DIAGRAM - 16