


## SCHEMATIC DIAGRAM - 9

B DVD MODULE 2 (HIND) CIRCUIT


: +B SIGNAL LINE



## SCHEMATIC DIAGRAM - 10

**B** DVD MODULE 2 (HIND) CIRCUIT

— : +B SIGNAL LINE


C4208  
0.1C4209  
0.1

## SCHEMATIC DIAGRAM - 11


**B** DVD MODULE 2 (HIND) CIRCUIT

: +B SIGNAL LINE

: DVD (VIDEO) SIGNAL LINE



**C**  
TO MAIN CIRCUIT  
(CN306) ON  
SCHEMATIC  
DIAGRAM - 18



**C**  
TO MAIN CIRCUIT  
(CN304) ON  
SCHEMATIC  
DIAGRAM - 18

LB3204 - 3208  
J0JCC0000119

FP3203