



SCHEMATIC DIAGRAM - 14

**TO H
TUNER CIRCUIT
(CP100) ON
SCHEMATIC
DIAGRAM - 31**



D TUNER
EXTENT
CIRCUIT




TO E
PANEL CIRCUIT
(CP601) ON
SCHEMATIC
DIAGRAM - 29

SCHEMATIC DIAGRAM - 15

C MAIN CIRCUIT

- - - : B SIGNAL LINE
 — : +B SIGNAL LINE
 0 : RECORD SIGNAL LINE
 → : MAIN SIGNAL LINE
 ↗ : AM/FM SIGNAL LINE




SCHEMATIC DIAGRAM - 16

C MAIN CIRCUIT

— : -B SIGNAL LINE
— : +B SIGNAL LINE

 : MAIN SIGNAL LINE



TO
PANEL CIRCUIT
(CP602) ON
SCHEMATIC DIAGRAM - 29

TO B
DVD MODULE 2 CIRCUIT
(FP4202) ON
SCHEMATIC DIAGRAM - 13



SCHEMATIC DIAGRAM - 17

C MAIN CIRCUIT

— — — : -B SIGNAL LINE

— : +B SIGNAL LINE


 : MAIN SIGNAL LINE



C MAIN CIRCUIT

— - : -B SIGNAL LINE
— : +B SIGNAL LINE

: DVD (VIDEO) SIGNAL LINE
 : MAIN SIGNAL LINE




B
TO
DVD MODULE 2 CIRCUIT
(FP3203) ON
SCHEMATIC DIAGRAM - 11

B
TO
DVD MODULE 2 CIRCUIT
(FP3202) ON
SCHEMATIC DIAGRAM - 11


C MAIN CIRCUIT

— : +B SIGNAL LINE  : DVD (VIDEO) SIGNAL LINE




C MAIN CIRCUIT

— : -B SIGNAL LINE
— : +B SIGNAL LINE



C MAIN CIRCUIT


— : -B SIGNAL LINE
— : +B SIGNAL LINE ➔ : MAIN SIGNAL LINE



SCHEMATIC DIAGRAM - 22


C MAIN CIRCUIT

-- : -B SIGNAL LINE
 — : +B SIGNAL LINE
 → : MAIN SIGNAL LINE




C MAIN CIRCUIT

— - - : -B SIGNAL LINE
— — : +B SIGNAL LINE : MAIN SIGNAL LINE



C MAIN CIRCUIT

— : +B SIGNAL LINE → : MAIN SIGNAL LINE



C MAIN CIRCUIT

-- : -B SIGNAL LINE
 — : +B SIGNAL LINE

