


SCHEMATIC DIAGRAM - 32

J DECK CIRCUIT

— : +B SIGNAL LINE
 [Symbol] : RECORD SIGNAL LINE
 [Symbol] : PLAYBACK SIGNAL LINE



J DECK CIRCUIT

 : PLAYBACK SIGNAL LINE

DECK CIRCUIT

Legend: : PLAYBACK SIGNAL LINE

Power Supply: +50V3.3 (C1054), +50V1 (C1048)

Transistors: Q1020, Q1021, Q1012, Q1013, Q1014, Q1015, Q1016, Q1017

Resistors: R1095, R1091, R1094, R1092, R1096, R1093, R1084, R1047, R1048, R1046, R1045, R1049, R1051, R1053, R1054, R1050, R1052, R1057, R1056, R1058, R1061, R1059, R1060

Capacitors: C1054, C1048, C1049, C1051, C1053, C1052, C1055

Motor: M (W1002)

Deck Muting Switch: Q1016 (KRA102STA)

Motor Switch: Q1017 (KTD1146YTA)

Buffer Amp: Q1014-Q1015 (B1ABC F000011)

Muting Switch: Q1020-Q1021 (KTD1304TA)

K DECK MECHANISM CIRCUIT

