




KITT

NOVA NTV-1434MK

14"



1. SPEAKER
2. POWER SWITCH
3. PROGRAM (+)
4. PROGRAM (-)
5. VOLUME (+)
6. VOLUME (-)
7. V-HOLD CONTROL
8. PICTURE SELECT BUTTON
9. PICTURE CONTROL (-) BUTTON
10. PICTURE CONTROL (+) BUTTON
11. HI-SPEED BUTTON
12. TUNING (-) BUTTON
13. TUNING (+) BUTTON
14. AV BUTTON
15. PRE-SET SWITCH
16. STORE BUTTON
17. BAND SELECT BUTTON
18. AERIAL TERMINAL
19. VIDEO INPUT JACK
20. AUDIO INPUT JACK

