



Displaying variable voltage on an LED bar using STM8S-DISCOVERY

Application overview

This application user manual provides a short description of how to use the ADC, Timer and GPIO peripherals.

Once the STM8S105C6T6 is powered-up through a USB cable connected to the host PC, the Timer triggers the ADC according to a user-defined period to convert the analog voltage provided by variable resistor RV1. The resulting average voltage measurement is represented on the LED bar.

Reference documents

- STM8S-DISCOVERY evaluation board user manual (UM0817).
- Developing and debugging your STM8S-DISCOVERY application code (UM0834).

1 Application description

1.1 Hardware requirements

No on-board resources are used.

External resources needed are:


- 4 LEDs: LD2, LD3, LD4, LD5
- 1 x 10 K Ω variable resistor: RV1
- 4 x 1 K Ω resistors: R1, R2, R3, R4
- 1 x 100 nF capacitor: C1

1.2 Application schematic

Capacitor C1 filters the voltage spike on PE6.

R1 and R4 limit the current going into LD2 and LD5.

Figure 1. Application schematic



1.3 Application principle

This application uses the ADC1, TIM1 and GPIO peripherals.

The analog input voltage signal from variable resistor RV1 is sampled and filtered on channel 9 of the ADC1 system (PE6), which is internally triggered by TIM1.

The average value of this signal is represented on the LED bar (LD2-5).

Table 1. Voltage and LED correspondence

Voltage (V)	LEDs switched on
0.0 - 0.7	None
0.7 - 2.0	LD2
2 - 3	LD2 + LD3
3 - 4.3 - 4	LD2 + LD3 + LD4
4 - 5	LD2 + LD3 + LD4 + LD5

2 Software description

This application uses neither the STM8S standard library nor the STM8 touch sensing library. The peripherals used in this application are:

- **ADC1**

ADC1 is used for voltage acquisition. It must be configured as follows:

- Single conversion mode
- External trigger by TIM1 TRGO
- $ADC_clock = F_{Master}/8$
- Left alignment result (otherwise a software modification is required to calculate the average value)
- Disable Schmitt trigger on ADC1 input 9: for analog input

- **TIM1**

TIM1 timer has two aims in this application:

- It wakes up the ADC for incoming conversion when the counter value reaches CCR1 (Capture/compare interrupt). This action is very useful to allow ADC stabilization time before the conversion.
- It sends a conversion trigger signal to launch the ADC conversion when the counter value reaches TIM1_ARR.


Using these two events you can easily manage ADC wake-up and conversion timing. TIM1 must be configured as follows:

- Compare-OC1REF trigger output
- PWM1 mode on PC1 (negative polarity): for testing purpose (to measure exactly the time allowed for stabilization)

- **GPIO**

Configure PB0, PB1, PB2 and PB3 in output push/pull mode to control LEDs LD2, LD3, LD4 and LD5.

Figure 2. ADC1 acquisition principle




TIM1 is configured as an upcounting counter. When the compare/capture interrupt occurs, the ADC1 is woken up for the incoming conversion (the stabilization time of the ADC1 is respected before the ADC conversion). On TIM1 TRGO, the ADC1 starts the conversion. When the conversion is finished, the result is stored in RAM and the ADC1 is powered down until the next compare/capture interrupt. When 8 conversion results have been stored, the main routine calculates the average of these results and displays it on the LED bar.

Note: OC1REF complementary signal is forced out on CC1 output pin (PC1) for test purposes.

2.1 Application software flowcharts

2.1.1 Main loop flowchart

Figure 3. Main loop flowchart




2.1.2 ADC1 interrupt routine

This interrupt occurs when the ADC1 has finished an analog to digital conversion. Every time it occurs the conversion result is stored in a table called AD. When this table is full the variable `AD_SampRdy` is set to 1 and the AD table is treated by the main routine (it calculates the average of the stored values). The ADC is switched off at the end of the interrupt routine.

Note: The result is stored only if the previous AD table has been treated by the main routine.


Figure 4. ADC1 EOC interrupt flowchart



2.1.3 TIM1 capture/compare interrupt

This interrupt occurs each time the TIM1 counter value is equal to the Compare register value CCR1. During this interrupt process, conversion is triggered by setting the ADON bit of the CR1 register to 1.

Figure 5. TIM1 capture/compare flowchart



3 Revision history

Table 2. Document revision history

Date	Revision	Changes
27-Nov-2009	1	Initial release.

Please Read Carefully:

Information in this document is provided solely in connection with ST products. STMicroelectronics NV and its subsidiaries ("ST") reserve the right to make changes, corrections, modifications or improvements, to this document, and the products and services described herein at any time, without notice.

All ST products are sold pursuant to ST's terms and conditions of sale.

Purchasers are solely responsible for the choice, selection and use of the ST products and services described herein, and ST assumes no liability whatsoever relating to the choice, selection or use of the ST products and services described herein.

No license, express or implied, by estoppel or otherwise, to any intellectual property rights is granted under this document. If any part of this document refers to any third party products or services it shall not be deemed a license grant by ST for the use of such third party products or services, or any intellectual property contained therein or considered as a warranty covering the use in any manner whatsoever of such third party products or services or any intellectual property contained therein.

UNLESS OTHERWISE SET FORTH IN ST'S TERMS AND CONDITIONS OF SALE ST DISCLAIMS ANY EXPRESS OR IMPLIED WARRANTY WITH RESPECT TO THE USE AND/OR SALE OF ST PRODUCTS INCLUDING WITHOUT LIMITATION IMPLIED WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE (AND THEIR EQUIVALENTS UNDER THE LAWS OF ANY JURISDICTION), OR INFRINGEMENT OF ANY PATENT, COPYRIGHT OR OTHER INTELLECTUAL PROPERTY RIGHT.

UNLESS EXPRESSLY APPROVED IN WRITING BY AN AUTHORIZED ST REPRESENTATIVE, ST PRODUCTS ARE NOT RECOMMENDED, AUTHORIZED OR WARRANTED FOR USE IN MILITARY, AIR CRAFT, SPACE, LIFE SAVING, OR LIFE SUSTAINING APPLICATIONS, NOR IN PRODUCTS OR SYSTEMS WHERE FAILURE OR MALFUNCTION MAY RESULT IN PERSONAL INJURY, DEATH, OR SEVERE PROPERTY OR ENVIRONMENTAL DAMAGE. ST PRODUCTS WHICH ARE NOT SPECIFIED AS "AUTOMOTIVE GRADE" MAY ONLY BE USED IN AUTOMOTIVE APPLICATIONS AT USER'S OWN RISK.

Resale of ST products with provisions different from the statements and/or technical features set forth in this document shall immediately void any warranty granted by ST for the ST product or service described herein and shall not create or extend in any manner whatsoever, any liability of ST.

ST and the ST logo are trademarks or registered trademarks of ST in various countries.

Information in this document supersedes and replaces all information previously supplied.

The ST logo is a registered trademark of STMicroelectronics. All other names are the property of their respective owners.

© 2009 STMicroelectronics - All rights reserved

STMicroelectronics group of companies

Australia - Belgium - Brazil - Canada - China - Czech Republic - Finland - France - Germany - Hong Kong - India - Israel - Italy - Japan - Malaysia - Malta - Morocco - Philippines - Singapore - Spain - Sweden - Switzerland - United Kingdom - United States of America

www.st.com

