


H TUNER CIRCUIT

— : +B SIGNAL LINE → : AM SIGNAL LINE
 ◻ : FM OSC SIGNAL LINE □ : FM SIGNAL LINE ■■■ : AM OSC SIGNAL LINE


I TUNER PACK CIRCUIT



SCHEMATIC DIAGRAM - 31

H TUNER CIRCUIT

— : +B SIGNAL LINE □ : FM SIGNAL LINE → : AM SIGNAL LINE ── : AM OSC SIGNAL LINE



D
TO D
TUNER EXTENT CIRCUIT
(CP702) ON
SCHEMATIC
DIAGRAM - 14