

SCHEMATIC DIAGRAM - 3


B

DVD MODULE 2 (FORE) CIRCUIT

→ : CD-DA SIGNAL LINE

— : +B SIGNAL LINE

A
TO
DVD MODULE 1
CIRCUIT
(FP5102) ON
SCHEMATIC
DIAGRAM - 2



SCHMATIC DIAGRAM - 4

B DVD MODULE 2 (FORE) CIRCUIT

— : +B SIGNAL LINE

